





MOD.	TELEDATA ONE	
N°	FAMILY	TYPE
007	FIRE SYSTEM	TELEDATA ONE SUPERVISIONE




PC WinWatch Teledata




BMS Supervisore Meccanico/Elettrico




MCTGWMDB  
Interfaccia ModBus




ONEKD




FIRE NO.1





FIRE NO.2




FIRE NO.32




FIRE NO...




mod.SF5100




mod.SF5200




mod.SF5300



mod.FDF1500




mod.FDF1500




mod.FDMM01S




ALLARME  
INCENDIO




mod.FDMM12




mod.FDBF100A RECEIVER - RICEVITORE




mod.FDMM02




mod.FD\_M0412E



mod.FD\_M5411E-F




mod.FDMM02




mod.G55 500V




mod.SF105B




mod.FDMM01S




mod.FDR90 RECEIVER - RICEVITORE



mod.FDMM12



mod.FDALW5M00



mod.FDVCP500