


# System ONE Apollo



\* = The devices with \* next to the product code are also compatible with Core Protocol

- TCIP NETWORK (CAT5 cable)
- RS485 LINE (Shielded, ant flame cable with 2 connectors for power supply and 2 connectors RS484 for signal)
- POWER SUPPLY AND SIGNAL (Shielded, ant flame cable with 2 connectors for signal and power supply)
- WIRELESS (Radio connection with 870 MHZ Frequency)

- SIGNAL (Shielded, ant flame cable with 2 connectors for power supply and 2 connectors RS484 for signal)
- NETWORK LOOP (Cat 5 cable)


- USB (Upload download programmazione)
- CLOSE LOOP WITH POWER SUPPLY (Shielded, ant flame cable with 2 connectors for signal and power supply)

(x) = Maximum Number of connected device. The devices can be added together ex: (x) + (x)

[x] = Maximum Number of connected device. The device cannot be added together ex: (x) or (x)



# System ONE Argus



**TCP/IP NETWORK**  
(CAT5 cable)

**RS485 LINE**  
(Shielded, ant flame cable with 2 connectors for power supply and 2 connectors RS484 for signal)

**SIGNAL**  
(Shielded, ant flame cable with 2 connectors for power supply and 2 connectors RS484 for signal)

**USB**  
(Upload download programmazione)

**(x) = Maximum Number of connected device.**  
The devices can be added together ex: (x) + (x)

**POWER SUPPLY AND SIGNAL**  
(Shielded, ant flame cable with 2 connectors for signal and power supply)

**WIRELESS**  
(Radio connection with 870 MHZ Frequency)

**NETWORK LOOP**  
(Cat 5 cable)

**CLOSE LOOP WITH POWER SUPPLY**  
(Shielded, ant flame cable with 2 connectors for signal and power supply)

**[x] = Maximum Number of connected device.**  
The device cannot be added together ex: (x) or (x)

